

AR-15-9 - CAL. 9MM

Due to many requests for a reliable AR15 9mm system, we are now pleased to present our Schmeisser AR15-9 product line after a long development time. Our new rifle is not only completely operable from both sides, we have also optimized the feed and the mass closure. No matter for which requirements, static or dynamic, with the Schmeisser AR15-9 you have the ideal rifle.

- NAME: AR15-9 S4F
- SYSTEM: Semi-automatic rifle
- CALIBER: 9×19
- WEIGHT: 3.040 g
- LENGTH: 69.3 cm collapsed, 76.9 cm extended
- BARREL: 26.7 cm
- TWIST: 1:10
- MAGAZINE: 10 rds

NO IMAGE
AVAILABLE

Attributes

- Name: SCHMEISSER AR-15-9 - CAL. 9MM
- Manufacturer: SCHMEISSER
- Product no.: EU2004550
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 10.5"
- Caliber: 9mm
- Cartridge: 9 x 19
- Color: Black
- Handguard: Carbine
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-10
- EAN: 4251366502059

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SCHMEISSER AR159 KAL. 9MM](#)
- [English: Safety Instruction Guide for SCHMEISSER AR159 CAL. 9MM](#)

Sicherheitshinweise für die SCHMEISSER AR159 KAL. 9MM

Einführung

Herzlichen Glückwunsch zum Erwerb der SCHMEISSER AR159 KAL. 9MM. Diese Anleitung bietet wichtige Informationen zur sicheren Nutzung, Installation und Entsorgung des Produkts. Bitte lesen Sie alle Anweisungen sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Waffe nur in einem sicheren und kontrollierten Umfeld verwenden.
- Bewahren Sie die Waffe immer entladen und in einem sicheren Bereich auf, wenn sie nicht in Gebrauch ist.
- Halten Sie die Waffe von Kindern und unbefugten Personen fern.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, während Sie die Waffe benutzen.
- Überprüfen Sie regelmäßig die Waffe auf Schäden oder Abnutzung.
- Befolgen Sie alle lokalen Gesetze und Vorschriften bezüglich des Besitzes und der Verwendung von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie ausschließlich die empfohlene Munition (Kaliber 9mm, Patrone 9 x 19).
- Achten Sie darauf, dass der Lauf frei von Verstopfungen ist, bevor Sie die Waffe abfeuern.
- Halten Sie den Finger außerhalb des Abzugsbügels, bis Sie bereit sind, zu schießen.
- Zielen Sie niemals auf etwas, das Sie nicht treffen möchten.
- Seien Sie sich der Umgebung bewusst und stellen Sie sicher, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Lassen Sie die Waffe niemals unbeaufsichtigt, insbesondere wenn sie geladen ist.

Anweisungen zur Installation und Nutzung

1. Installation:

- Überprüfen Sie die Waffe auf Vollständigkeit und Unversehrtheit.
- Montieren Sie das Zubehör gemäß den Herstelleranweisungen.
- Stellen Sie sicher, dass alle Teile fest und sicher angebracht sind.

2. Nutzung:

- Laden Sie die Waffe gemäß den Anweisungen im Benutzerhandbuch.
- Stellen Sie sicher, dass die Sicherung aktiviert ist, wenn die Waffe nicht verwendet wird.
- Führen Sie alle Schussübungen in einem dafür vorgesehenen Bereich durch.
- Nach dem Schießen, entladen Sie die Waffe und reinigen Sie sie regelmäßig.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Bringen Sie die Waffe zu einem autorisierten Fachhändler oder einer Sammelstelle, wenn sie nicht mehr benötigt wird.
- Stellen Sie sicher, dass alle Teile der Waffe sicher und umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zur Sicherheit wenden Sie sich bitte an den Hersteller oder einen qualifizierten Fachmann. Achten Sie darauf, dass alle Sicherheitsanfragen an eine EUbasierte Kontaktstelle gerichtet werden.

Bitte beachten Sie, dass die Einhaltung dieser Sicherheitsrichtlinien nicht nur für Ihre eigene Sicherheit, sondern auch für die Sicherheit anderer von größter Bedeutung ist. Halten Sie sich stets an die besten Praktiken im Umgang mit Feuerwaffen.

Safety Instruction Guide for SCHMEISSER AR159 CAL. 9MM

Introduction

Thank you for choosing the SCHMEISSER AR159 CAL. 9MM. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your rifle. Please read this manual carefully before use.

General Safety Guidelines

- Ensure that you are familiar with the operation of firearms and always handle them responsibly.
- Always treat every firearm as if it is loaded.
- Store firearms securely and out of reach of children and unauthorized users.
- Use appropriate safety gear when handling firearms, including eye and ear protection.
- Be aware of your surroundings and ensure that you have a safe shooting environment.
- Follow all local laws and regulations regarding firearm ownership and use.
- Regularly inspect your firearm for any signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always keep the muzzle pointed in a safe direction.
- Do not place your finger on the trigger until you are ready to shoot.
- Ensure that the safety mechanism is engaged until you are prepared to fire.
- Use only the recommended ammunition (9×19) for your firearm to prevent malfunctions.
- Be cautious of the potential for ricochet when shooting in areas with hard surfaces.
- Avoid shooting at hard objects or water.
- Do not attempt to modify your firearm; any alterations can lead to unsafe conditions.
- Do not use your firearm under the influence of drugs or alcohol.

Instructions for Installation and Usage

Installation

- Ensure that the rifle is unloaded before any installation.
- Follow manufacturer guidelines for attaching any accessories or modifications.
- Ensure that all parts are securely fastened before use.

Usage

- To operate the SCHMEISSER AR159, follow these steps:
 1. Ensure the rifle is pointed in a safe direction.
 2. Check that the safety is engaged.
 3. Load the magazine with the appropriate ammunition (10 rds).
 4. Insert the magazine into the rifle until it clicks into place.
 5. Pull the charging handle to chamber a round.
 6. Off the safety mechanism when you are ready to shoot.
 7. Aim at your target and gently squeeze the trigger.
 8. After firing, continue to keep the muzzle pointed in a safe direction and engage the safety.

Disposal Instructions

- Dispose of your firearm in accordance with local laws and regulations.

- If you need to dispose of ammunition, contact local authorities for proper disposal methods.
- Do not dispose of firearms or ammunition in regular trash.

Contact Information for Further Support

For any safety inquiries or further assistance, please consult the manufacturer's website or contact your local authorized dealer.