

AR-15 - 16.75" - CAL. 223 REM.

The Schmeisser AR15 is a special SL rifle for hunting and safety applications with a free swinging barrel. This firearm with No Flash flash muzzle suppressor, a slim M-Lok handguard and a adjustable gas block made of steel. The Two-Stage trigger guarantees a clearly defined dry trigger. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. Standard delivery with a 10 round magazine and a flip-up sight.

- NAME: AR15 M5FL
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 3.550 g
- LENGTH: 87.5 cm collapsed, 95 cm extended
- BARREL: 42.5 cm
- TWIST: 1:9
- MAGAZINE: 10 rds

NO IMAGE
AVAILABLE

Attributes

- Name: SCHMEISSER AR-15 - 16.75" - CAL. 223 REM.
- Manufacturer: SCHMEISSER
- Product no.: EU2004555
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 16.75"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Black
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-9
- EAN: 4251366502103

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schmeisser AR15 16,75" Kal. 223 Rem.](#)
- [English: Safety Instruction Guide for SCHMEISSER AR15 16.75" CAL. 223 REM.](#)

Sicherheitshinweise für die Schmeisser AR15 16,75" Kal. 223 Rem.

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Schmeisser AR15! Diese Anleitung bietet wichtige Sicherheitshinweise, um eine sichere und effektive Nutzung Ihres Gewehrs zu gewährleisten. Bitte lesen Sie diese Hinweise sorgfältig durch, um Risiken zu vermeiden und die Sicherheit zu maximieren.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Bedienungsanleitung vollständig gelesen und verstanden haben, bevor Sie das Produkt verwenden.
- Bewahren Sie das Gewehr und Munition außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Verwenden Sie das Gewehr nur, wenn Sie über die erforderlichen Kenntnisse und Erfahrungen im Umgang mit Feuerwaffen verfügen.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, wenn Sie das Gewehr verwenden.
- Informieren Sie sich über die Gesetze und Vorschriften in Ihrem Land oder Ihrer Region bezüglich des Besitzes und Gebrauchs von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Überprüfen Sie vor jedem Gebrauch, ob das Gewehr entladen ist.
- Halten Sie den Abzug nicht gedrückt, während Sie das Gewehr laden oder entladen.
- Richten Sie das Gewehr niemals auf Menschen oder Tiere.
- Stellen Sie sicher, dass der Lauf frei von Hindernissen ist, bevor Sie abdrücken.
- Verwenden Sie nur die empfohlene Munition (.223 Remington) für Ihr Gewehr.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, insbesondere wenn es geladen ist.
- Verwenden Sie das Gewehr nicht unter dem Einfluss von Alkohol oder Drogen.

Anweisungen zur Installation und Nutzung

- **Installation:**
 - Befolgen Sie die Anweisungen in der Bedienungsanleitung zur Montage von Zubehörteilen wie Zielfernrohren oder Vorderschäften.
 - Stellen Sie sicher, dass alle Teile sicher befestigt sind, bevor Sie das Gewehr verwenden.
- **Nutzung:**
 - Laden Sie das Gewehr gemäß den Anweisungen in der Bedienungsanleitung.
 - Überprüfen Sie regelmäßig den Zustand des Gewehrs und führen Sie Wartungsarbeiten durch, um sicherzustellen, dass es in einwandfreiem Zustand bleibt.
 - Üben Sie regelmäßig, um Ihre Fähigkeiten im Umgang mit dem Gewehr zu verbessern.

Entsorgungsanweisungen

- Entsorgen Sie alte oder beschädigte Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Geben Sie das Gewehr nur an autorisierte Händler oder Fachleute ab, wenn Sie es nicht mehr benötigen.
- Halten Sie sich an alle geltenden Gesetze und Vorschriften zur Entsorgung von Feuerwaffen.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich an den Händler, bei dem Sie das Gewehr gekauft haben, oder an einen autorisierten SchmeisserServicepartner.

Bitte beachten Sie, dass Sie alle Sicherheitsrichtlinien stets befolgen sollten. Ihre Sicherheit und die Sicherheit anderer hat oberste Priorität.

Safety Instruction Guide for SCHMEISSER AR15 16.75" CAL. 223 REM.

Introduction

Thank you for choosing the SCHMEISSER AR15 rifle. This guide provides essential safety instructions to ensure the safe use, handling, and maintenance of your firearm. Please read this document carefully before using the product. Adhering to these guidelines will help prevent accidents and ensure a safe experience.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Store firearms securely and out of reach of children and unauthorized users.
- Never place your finger on the trigger until you are ready to shoot.
- Be aware of your surroundings and ensure a clear line of fire.
- Use appropriate eye and ear protection while shooting.
- Ensure the firearm is properly maintained and regularly inspected for safety.
- Do not use ammunition that is not specified for this firearm.
- Always follow local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure the safety selector is in the "safe" position until you are ready to fire.
- Familiarize yourself with the operation of the charging handle, magazine trigger, and bolt catch before using the firearm.
- Avoid using the firearm when under the influence of alcohol or drugs.
- Do not attempt to modify or alter the firearm in any way.
- If a malfunction occurs, keep the firearm pointed in a safe direction and follow proper clearing procedures.
- Always use the firearm in a designated shooting area or range.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure all accessories, such as scopes or sights, are securely mounted according to the manufacturer's instructions.
- Use only compatible accessories that are designed for the SCHMEISSER AR15.

2. Loading the Firearm:

- Ensure the firearm is on "safe."
- Insert the magazine into the magazine well until it clicks into place.
- Pull the charging handle to chamber a round while keeping the muzzle pointed in a safe direction.

3. Firing the Firearm:

- Once ready to fire, switch the safety selector to "fire."
- Aim at your target and gently squeeze the trigger to fire.
- After firing, keep the firearm pointed downrange and assess the situation before ejecting the magazine or chambering another round.

4. Unloading the Firearm:

- Switch the safety selector to "safe."
- Remove the magazine from the firearm.
- Pull the charging handle to eject any chambered round.
- Visually and physically inspect the chamber to ensure it is empty.

5. Cleaning and Maintenance:

- Regularly clean the firearm according to the manufacturer's instructions.
- Use appropriate cleaning supplies and ensure the firearm is unloaded before cleaning.
- Store the firearm in a cool, dry place to prevent rust and corrosion.

Disposal Instructions

- Dispose of any unused or expired ammunition in accordance with local regulations.
- When disposing of the firearm, contact a licensed firearms dealer or local authorities for guidance on safe disposal methods.
- Ensure that all components of the firearm are rendered inoperable before disposal.

Contact Information for Further Support

For any questions or concerns regarding the SCHMEISSER AR15, please refer to the manufacturer's customer service resources or your local firearms dealer for assistance.

Thank you for your attention to these safety instructions. Enjoy your experience with the SCHMEISSER AR15 rifle, and always prioritize safety.