

1911 - 5" - CAL. .45 ACP - Schmeisser 1911 - 5" - cal. .45 ACP - Thunder Bronze

The classic single-stack 1911 pistol – optimized to match the inventors vision. Every single accessory was brought to perfection with the experience of a century and the knowledge of a million shooters. As a result you get a reliable high performance gun with a bulls-eye accuracy.

- NAME: 1911 HUGO 5" with LPA-Sights
- SYSTEM: Pistol
- CALIBER: .45 ACP
- WEIGHT: 1.150 g
- LENGTH: 21.5 cm
- BARREL: 12.7 cm
- TWIST: 1:16
- MAGAZINE: 10 rds
- COLOR: Thunder Bronze

NO IMAGE
AVAILABLE

Attributes

- Name: Schmeisser 1911 - 5" - cal. .45 ACP - Thunder Bronze
- Manufacturer: SCHMEISSER
- Product no.: EU2005051
- Mfr. No.: SCH10-0132
- Barrel Length: 5"
- Caliber: 45 Colt
- Cartridge: 45 Auto (ACP)
- Color: Bronze
- Make: Colt
- Model: 1911
- Twist: 1-16
- EAN: 4251366502332

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SCHMEISSER 1911 5" KAL. .45 ACP](#)
- [English: Safety Instruction Guide for the SCHMEISSER 1911 5" CAL. .45 ACP](#)

Sicherheitshinweise für die SCHMEISSER 1911 5" KAL. .45 ACP

Einführung

Herzlichen Glückwunsch zum Erwerb Ihrer SCHMEISSER 1911 5" KAL. .45 ACP. Diese klassische Pistole wurde mit höchster Präzision und unter Berücksichtigung langjähriger Erfahrung entwickelt. Um die Sicherheit bei der Nutzung dieses Produkts zu gewährleisten, haben wir wichtige Sicherheitsrichtlinien und Anweisungen zusammengestellt. Bitte lesen Sie diese sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie die Pistole ausschließlich in Übereinstimmung mit den Anweisungen des Herstellers.
- Halten Sie die Pistole immer in einem sicheren Zustand und außerhalb der Reichweite von Kindern.
- Überprüfen Sie regelmäßig die Funktionalität und den Zustand der Waffe.
- Melden Sie unsichere Produkte oder Vorfälle umgehend den zuständigen Behörden.
- Informieren Sie sich über Rückrufaktionen auf der EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Stellen Sie sicher, dass die Waffe vor der Benutzung entladen ist.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Tragen Sie beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Achten Sie darauf, die Waffe niemals auf Personen oder Tiere zu richten.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Verwenden Sie die Pistole nur in dafür vorgesehenen Bereichen, die den gesetzlichen Anforderungen entsprechen.

Anweisungen für Installation und Nutzung

1. Vorbereitung der Waffe:

- Entfernen Sie die Waffe aus der Verpackung und überprüfen Sie, ob alle Teile vorhanden sind.
- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie sie handhaben.

2. Laden der Waffe:

- Verwenden Sie nur die empfohlene Munition (.45 ACP).
- Führen Sie die Munition gemäß den Anweisungen des Herstellers in das Magazin ein.

3. Shooting:

- Positionieren Sie sich in einer stabilen Schießhaltung.
- Ziehen Sie den Abzug vorsichtig, um einen Schuss abzugeben.
- Nach dem Schießen überprüfen Sie die Waffe und entladen Sie sie, wenn Sie fertig sind.

4. Reinigung und Wartung:

- Reinigen Sie die Waffe regelmäßig, um ihre Funktionsfähigkeit zu gewährleisten.
- Verwenden Sie geeignete Reinigungsmittel und Werkzeuge, die für die SCHMEISSER 1911 empfohlen werden.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Lagern Sie die Waffe und Munition sicher, bis Sie bereit sind, sie zu entsorgen oder zu verkaufen.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu Ihrer SCHMEISSER 1911 5" KAL. .45 ACP wenden Sie sich bitte an den Hersteller oder an den örtlichen Fachhändler. Sie sollten in der Lage sein, Ihnen die benötigte Unterstützung zu bieten.

Bitte beachten Sie, dass die Sicherheit und der verantwortungsvolle Umgang mit Ihrer Waffe oberste Priorität haben. Halten Sie sich an diese Richtlinien, um sicherzustellen, dass Sie und andere in Ihrer Umgebung geschützt sind.

Safety Instruction Guide for the SCHMEISSER 1911 5" CAL. .45 ACP

Introduction

Thank you for choosing the SCHMEISSER 1911 5" CAL. .45 ACP. This guide provides essential safety information to ensure the safe use and handling of your firearm. Please read this document carefully before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the firearm at anything you do not intend to shoot.
- Ensure the firearm is stored safely and securely when not in use.
- Always use the correct ammunition for your firearm.
- Be aware of your surroundings and ensure a clear shooting area.
- Do not consume alcohol or drugs before or during the use of the firearm.
- Regularly inspect your firearm for any signs of wear or damage.

Specific Safety Precautions for Use

- Only use the SCHMEISSER 1911 5" CAL. .45 ACP in accordance with the manufacturer's guidelines.
- Ensure that all users are trained and competent in the use of firearms.
- Do not attempt to modify or alter the firearm in any way.
- Use hearing and eye protection when shooting.
- Be mindful of the recoil and manage it appropriately.
- Always keep the firearm pointed in a safe direction when loading or unloading.
- Avoid using the firearm in wet or damp conditions to prevent malfunction.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the firearm from its packaging. Inspect for any visible damage.
2. **Loading the Magazine:**
 - Ensure the firearm is pointed in a safe direction.
 - Insert the magazine into the magazine well until it clicks into place.
 - Load the appropriate .45 ACP cartridges into the magazine, ensuring they are seated properly.
3. **Chambering a Round:**
 - With the safety on, pull the slide back to chamber a round.
 - Release the slide gently to avoid damaging the firearm.
4. **Firing:**
 - Ensure your stance is stable and your grip is firm.
 - Disengage the safety.
 - Aim at your target and squeeze the trigger gently.
5. **Clearing the Firearm:**
 - After firing, keep the firearm pointed in a safe direction.
 - Engage the safety before attempting to clear the firearm.
 - Remove the magazine and pull the slide back to eject any chambered round.

Disposal Instructions

- Do not dispose of the firearm in regular trash.
- Contact local authorities for guidance on safe disposal methods.

- Ensure that all ammunition is disposed of according to local regulations.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the contact information provided with your product or visit the manufacturer's website.

Conclusion

Your safety is of utmost importance. By following these guidelines and instructions, you can help ensure a safe and enjoyable experience with your SCHMEISSER 1911 5" CAL. .45 ACP. Always prioritize safety and responsibility when handling firearms.