

AR-15 DMR - 18" - CAL. 223 REM.

The Marksman series is the new AR15 benchmark when it comes to maximum precision and handling. It's the premier choice for the demanding shooter, who expects perfection right-out-of-the-box. Every single Schmeisser AR15 is test-fired with different ammunition and magazines before it leaves the factory. So you can count on your complete gun right from the beginning. All Schmeisser AR15 are fully ambidextrous.

- NAME: AR15 DMR 18"
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 4.350 g
- LENGTH: 95 cm collapsed, 104 cm extended
- BARREL: 46 cm
- TWIST: 1:8
- MAGAZINE: 10 rds
- COLOR: RAL8000

NO IMAGE
AVAILABLE

Attributes

- Name: SCHMEISSER AR-15 DMR - 18" - CAL. 223 REM.
- Manufacturer: SCHMEISSER
- Product no.: EU2004564
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 18"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Brown/Gold
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-8
- EAN: 4251366502202

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den SCHMEISSER AR15 DMR 18" KAL. 223 REM.](#)
- [English: Safety Instruction Guide for SCHMEISSER AR15 DMR 18" CAL. 223 REM.](#)

Sicherheitshinweise für den SCHMEISSER AR15 DMR 18" KAL. 223 REM.

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des SCHMEISSER AR15 DMR. Dieses Produkt wurde entwickelt, um Ihnen eine präzise und verlässliche Schusswaffe zu bieten. Um Ihre Sicherheit und die Sicherheit anderer zu gewährleisten, ist es wichtig, die folgenden Sicherheitsanweisungen zu befolgen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Waffe nur in einem sicheren und kontrollierten Umfeld verwenden.
- Halten Sie die Waffe immer in einem sicheren Zustand, bis Sie bereit sind, zu schießen.
- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Bewahren Sie die Waffe und Munition außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie regelmäßig den Zustand der Waffe und der Munition, um sicherzustellen, dass sie in einwandfreiem Zustand sind.
- Melden Sie unsichere Produkte oder Vorfälle an die zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Achten Sie darauf, dass der Lauf der Waffe frei von Verstopfungen ist, bevor Sie schießen.
- Verwenden Sie nur die vom Hersteller empfohlene Munition (.223 Remington).
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Schießen Sie niemals in Richtung von Menschen oder Tieren.
- Achten Sie beim Laden und Entladen der Waffe darauf, dass der Abzug nicht versehentlich betätigt wird.
- Lassen Sie die Waffe niemals unbeaufsichtigt, wenn sie geladen ist.

Anweisungen für Installation und Nutzung

1. Installation:

- Überprüfen Sie die Waffe auf Beschädigungen oder Mängel.
- Stellen Sie sicher, dass alle Teile ordnungsgemäß montiert sind.
- Lesen Sie die Bedienungsanleitung gründlich durch, bevor Sie die Waffe verwenden.

2. Nutzung:

- Laden Sie die Waffe nur in einem sicheren Bereich.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Zielen Sie immer in eine sichere Richtung.
- Nach dem Schießen, entladen Sie die Waffe und überprüfen Sie, ob sie leer ist.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere gefährliche Materialien gemäß den lokalen Vorschriften.
- Bringen Sie nicht mehr benötigte Waffen und Munition zu einer autorisierten Sammelstelle oder einem Fachhändler.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrem Produkt stehen Ihnen verschiedene Ressourcen zur Verfügung. Bitte wenden Sie sich an den Hersteller oder besuchen Sie die offizielle Website.

Schlussfolgerung

Die Sicherheit bei der Verwendung des SCHMEISSER AR15 DMR ist von größter Bedeutung. Indem Sie diese Sicherheitsanweisungen befolgen, tragen Sie dazu bei, ein sicheres Umfeld für sich und andere zu gewährleisten. Vielen Dank, dass Sie sich für SCHMEISSER entschieden haben.

Safety Instruction Guide for SCHMEISSER AR15 DMR 18" CAL. 223 REM.

Introduction

Thank you for choosing the SCHMEISSER AR15 DMR. This semiautomatic rifle is designed for precision and performance. To ensure your safety and the safe operation of your firearm, please read this safety instruction guide thoroughly before use.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Do not rely on the safety mechanism; always keep your finger off the trigger until you are ready to shoot.
- Store the firearm in a secure location, out of reach of children and unauthorized persons.
- Always use the correct ammunition specified for your firearm.
- Wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure that you have a clear target before firing.
- Regularly inspect your firearm for any signs of wear or damage.

Specific Safety Precautions for Use

- Ensure that the firearm is in good working order before each use.
- Do not modify the firearm in any way that could affect its safety or performance.
- Be cautious of the environmental conditions, such as wind and visibility, which may affect shooting accuracy.
- Avoid distractions and maintain focus when handling the firearm.
- If you experience a misfire, wait at least 30 seconds before attempting to clear the firearm.
- Always clean and maintain your firearm according to the manufacturer's guidelines.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded before installation.
- Follow the manufacturer's instructions for any accessories or attachments.
- Securely mount any additional components, ensuring they do not interfere with the operation of the firearm.

2. Usage:

- Load the magazine with the correct ammunition (.223 Remington).
- Insert the magazine into the firearm until it clicks into place.
- Pull the charging handle to chamber a round.
- Aim at your target, ensuring the area is safe and clear.
- Press the trigger gently to fire.
- After firing, keep the firearm pointed downrange until you are finished shooting.
- Unload the firearm after use and store it securely.

Disposal Instructions

- Dispose of any unused ammunition according to local regulations.
- Do not throw away firearms in regular trash. Contact local law enforcement or a licensed dealer for

proper disposal methods.

- Ensure that any firearm parts are disposed of in a manner that prevents unauthorized access.

Contact Information for Further Support

For any safety inquiries or concerns regarding your SCHMEISSER AR15 DMR, please refer to the manufacturer's contact details provided in the product documentation. It is important to have access to support for any safetyrelated questions or issues.

Important Note: This safety instruction guide is designed to comply with the EU General Product Safety Regulation (GPSR). It aims to ensure the safe use of the SCHMEISSER AR15 DMR and to protect consumers from potential hazards associated with firearms. Always stay informed about recall updates or safety alerts through the EU's Safety Gate platform.

Stay safe and enjoy your shooting experience responsibly.