

AR-15 DYNAMIC - 10.5" - CAL. 223 REM.

The skeletonized and heavily weight-reduced Schmeisser AR15 Dynamic with its perfect full equipment is our particularly leading universal rifle for hunting applications. It has a slim keymod handguard and a gas block made of steel. This rifle has a weight-reduced, free-swinging barrel with NOREC compensator, a slim M-Lok forearm and a adjustable steel gas block. The Dynamic Trigger ensures a particularly fast shot release. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. The solid reinforcement on the lower increases the stability many times over compared to conventional AR15. Standard delivery includes 10 round magazine and flip-up sight.

NO IMAGE
AVAILABLE

- NAME: AR15 Dynamic 10.5"
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 2.750 g
- LENGTH: 71 cm collapsed, 80.5 cm extended
- BARREL: 26.5 cm
- TWIST: 1:9
- MAGAZINE: 10 rds
- COLOR: grey

Attributes

- Name: SCHMEISSER AR-15 DYNAMIC - 10.5" - CAL. 223 REM.
- Manufacturer: SCHMEISSER
- Product no.: EU2004567
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 10.5"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Grey
- Handguard: Mid-Length
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-9
- EAN: 4251366502240

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SCHMEISSER AR15 DYNAMIC 10,5" KAL. 223 REM.](#)
- [English: Safety Instruction Guide for SCHMEISSER AR15 DYNAMIC 10.5" CAL. 223 REM.](#)

Sicherheitshinweise für die SCHMEISSER AR15 DYNAMIC 10,5" KAL. 223 REM.

Einführung

Die SCHMEISSER AR15 DYNAMIC ist eine hochentwickelte Universalwaffe, die sowohl für Jagd als auch für sportliche Anwendungen geeignet ist. Um die Sicherheit bei der Verwendung dieses Produkts zu gewährleisten, ist es wichtig, die folgenden Sicherheitshinweise und Anweisungen sorgfältig zu befolgen.

Allgemeine Sicherheitsrichtlinien

- Verwende die Waffe nur in Übereinstimmung mit den geltenden Gesetzen und Vorschriften.
- Halte die Waffe immer in einem sicheren Zustand, bis du bereit bist, sie zu benutzen.
- Richte die Mündung niemals auf etwas, das du nicht treffen möchtest.
- Behandle jede Waffe, als ob sie geladen wäre.
- Halte Kinder und unbefugte Personen von der Waffe fern.
- Verwende nur die vom Hersteller empfohlenen Munitionstypen.
- Überprüfe die Waffe regelmäßig auf Beschädigungen oder Abnutzung.
- Bei Anzeichen von Fehlfunktionen oder Schäden, wende dich sofort an einen Fachmann.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwende die Waffe nur auf dafür vorgesehenen Schießständen oder in sicheren Jagdgebieten.
- Trage immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Achte darauf, dass deine Finger nicht am Abzug sind, bis du bereit bist, zu schießen.
- Halte stets einen sicheren Abstand zu anderen Personen während des Schießens.
- Achte auf die Umgebung und sei dir möglicher Gefahren bewusst, wie z.B. Tiere, andere Schützen oder Hindernisse.
- Bei der Verwendung des NOREC Kompensators, achte darauf, dass du die Waffe sicher hältst, um Rückstoß zu kontrollieren.

Anweisungen zur Installation und Nutzung

• Installation des Vorderschafts:

1. Entferne die Waffe aus dem gesicherten Zustand und stelle sicher, dass sie leer ist.
2. Befestige den MLoc Vorderschaft gemäß den Anweisungen im Handbuch.
3. Überprüfe die Festigkeit aller Schrauben und Befestigungen.

• Verwendung des Dynamic Triggers:

1. Stelle sicher, dass die Waffe sicher ist, bevor du den Abzug betätigst.
2. Übe den Abzug mit leichtem Druck, um die Schussabgabe zu optimieren.
3. Achte darauf, dass der Abzug nicht versehentlich betätigt wird.

• Anpassung des Stahlgasblocks:

1. Stelle den Gasblock entsprechend deinen Bedürfnissen ein.
2. Überprüfe nach der Anpassung die Funktionalität der Waffe.

• Laden und Entladen der Waffe:

1. Lade das 10 Schuss Magazin gemäß den Anweisungen.

2. Entlade die Waffe immer in einem sicheren Bereich, bevor du sie transportierst.

Entsorgungsanweisungen

- Entsorge leere Patronen und Munition gemäß den lokalen Vorschriften.
- Wende dich an autorisierte Sammelstellen für die Entsorgung von Waffen und Munition.
- Beachte, dass die unsachgemäße Entsorgung von Munition gefährlich sein kann und strafrechtlich verfolgt werden kann.

Kontaktinformationen für weitere Unterstützung

- Bei Fragen oder Bedenken zur Sicherheit oder Funktionsweise der SCHMEISSER AR15 DYNAMIC, wende dich an den Hersteller oder einen qualifizierten Fachmann.

Diese Sicherheitshinweise sind wichtig, um sicherzustellen, dass du die SCHMEISSER AR15 DYNAMIC sicher und verantwortungsbewusst verwendest. Halte dich an die oben genannten Richtlinien, um Risiken zu minimieren und eine sichere Nutzung zu gewährleisten.

Safety Instruction Guide for SCHMEISSER AR15 DYNAMIC 10.5" CAL. 223 REM.

Introduction

Thank you for choosing the SCHMEISSER AR15 DYNAMIC. This semiautomatic rifle is designed for hunting applications and offers a lightweight, versatile option for users. Please read this safety instruction guide carefully to ensure safe and responsible use of your firearm.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Ensure the firearm is stored in a secure location, out of reach of children and unauthorized users.
- Always wear appropriate eye and ear protection when using the firearm.
- Be aware of your surroundings and ensure you have a safe backstop when shooting.
- Familiarize yourself with the local laws and regulations regarding firearm ownership and use.
- Regularly inspect the firearm for any signs of wear or damage.

Specific Safety Precautions for Use

- Always use the correct caliber ammunition as specified: .223 Remington.
- Ensure that the magazine is properly inserted before attempting to fire.
- Do not attempt to modify the firearm or use aftermarket parts that are not approved by the manufacturer.
- If you experience a malfunction, follow the manufacturer's guidelines for clearing the issue safely.
- Never point the firearm at anything you do not intend to shoot.
- Use the safety selector to prevent accidental discharge when the firearm is not in use.
- Keep the firearm clean and wellmaintained to ensure its safe operation.

Instructions for Installation and Usage

• Installation:

- Ensure you have a clean and safe workspace before handling the firearm.
- Inspect the rifle for any shipping damage before use.
- Attach any accessories (e.g., sights) according to the manufacturer's instructions.

• Usage:

- Before loading, ensure the firearm is pointed in a safe direction.
- Load the magazine with the correct .223 Remington ammunition.
- Insert the magazine into the rifle until it clicks into place.
- Pull the charging handle to chamber a round.
- To fire, aim at your target, ensure the safety selector is in the "fire" position, and gently squeeze the trigger.
- After firing, keep the firearm pointed downrange and wait for a few moments to ensure no further rounds are chambered.
- To unload, remove the magazine, pull the charging handle to eject any chambered round, and visually inspect the chamber to ensure it is clear.

Disposal Instructions

- Dispose of the firearm in accordance with local laws and regulations.
- Ensure that the firearm is rendered inoperable before disposal.
- Dispose of ammunition and firearm parts in a safe and responsible manner, following local hazardous waste guidelines.

Contact Information for Further Support

For any inquiries regarding safety, maintenance, or issues with your SCHMEISSER AR15 DYNAMIC, please refer to the manufacturer's website or contact your local authorized dealer. They can provide support and information regarding your product.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your SCHMEISSER AR15 DYNAMIC. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these important guidelines.