

## AR-15 DYNAMIC - 14.5" - CAL. 223 REM.

The skeletonized and heavily weight-reduced Schmeisser AR15 Dynamic with its perfect full equipment is our particularly leading universal rifle for hunting and sport applications. It has a slim keymod handguard and a gas block made of steel. This rifle has a weight-reduced, free-swinging barrel with NOREC compensator, a slim M-Lok forearm and a adjustable steel gas block. The Dynamic Trigger ensures a particularly fast shot release. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. The solid reinforcement on the lower increases the stability many times over compared to conventional AR15. Standard delivery includes 10 round magazine and flip-up sight.

NO IMAGE  
AVAILABLE

- NAME: AR15 Dynamic L 14.5"
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 2.900 g
- LENGTH: 80.5 cm collapsed, 90.5 cm extended
- BARREL: 37 cm
- TWIST: 1:9
- MAGAZINE: 10 rds
- COLOR: grey

### Attributes

- Name: SCHMEISSER AR-15 DYNAMIC - 14.5" - CAL. 223 REM.
- Manufacturer: SCHMEISSER
- Product no.: EU2004569
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 14.5"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Grey
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-9
- EAN: 4251366502264

# Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SCHMEISSER AR15 DYNAMIC 14,5" KAL. 223 REM.](#)
- [English: Safety Instruction Guide for SCHMEISSER AR15 DYNAMIC 14.5" CAL. 223 REM.](#)

# Sicherheitshinweise für die SCHMEISSER AR15 DYNAMIC 14,5" KAL. 223 REM.

## Einleitung

Herzlichen Glückwunsch zu Ihrem neuen Produkt, der SCHMEISSER AR15 DYNAMIC. Diese Anleitung bietet Ihnen wichtige Informationen zur sicheren Verwendung und Handhabung des Produkts. Bitte lesen Sie alle Anweisungen sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen.

## Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die örtlichen Gesetze und Vorschriften bezüglich des Besitzes und der Verwendung von Feuerwaffen kennen und befolgen.
- Halten Sie die Waffe immer in einem sicheren Zustand, bis Sie bereit sind, sie zu benutzen.
- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Bewahren Sie die Waffe und Munition an einem sicheren Ort auf, der für unbefugte Personen unzugänglich ist.
- Überprüfen Sie vor jeder Verwendung die Waffe auf Schäden oder Mängel.
- Informieren Sie sich über die richtige Handhabung und Verwendung von Feuerwaffen, um Unfälle zu vermeiden.

## Besondere Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, während Sie die Waffe benutzen.
- Halten Sie den Finger von dem Abzug, bis Sie bereit sind zu schießen.
- Richten Sie die Waffe niemals auf etwas, das Sie nicht treffen möchten.
- Achten Sie darauf, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Verwenden Sie nur die empfohlene Munition (.223 Remington) für die Waffe.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie die Waffe abfeuern.

## Anweisungen zur Installation und Nutzung

### • Installation:

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie mit der Installation von Zubehörteilen beginnen.
- Montieren Sie den MLok Vorderschaft gemäß den Anweisungen des Herstellers.
- Überprüfen Sie alle Befestigungen und stellen Sie sicher, dass sie fest sitzen.

### • Nutzung:

- Laden Sie die Waffe gemäß den Anweisungen im Handbuch.
- Stellen Sie den verstellbaren Stahlgasblock auf die gewünschte Einstellung ein.
- Verwenden Sie den Dynamic Trigger für eine schnelle Schussabgabe.
- Betätigen Sie die Sicherung, bevor Sie die Waffe transportieren oder lagern.

## Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie sie entsorgen oder an einen anderen Ort transportieren.
- Wenden Sie sich an eine autorisierte Entsorgungsstelle oder einen Fachmann, um sicherzustellen, dass

die Waffe sicher entsorgt wird.

## **Kontaktinformationen für weitere Unterstützung**

Für weitere Informationen oder bei Fragen zur Sicherheit Ihres Produkts wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben.

Bitte beachten Sie, dass diese Sicherheitsanweisungen nicht alle möglichen Risiken abdecken. Es liegt in Ihrer Verantwortung, sich über die sichere Handhabung von Feuerwaffen zu informieren und sicherzustellen, dass Sie alle notwendigen Vorsichtsmaßnahmen treffen.

# Safety Instruction Guide for SCHMEISSER AR15 DYNAMIC 14.5" CAL. 223 REM.

## Introduction

Thank you for choosing the SCHMEISSER AR15 DYNAMIC. This semiautomatic rifle is designed for both hunting and sport applications. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Ensure that you understand the operation of your rifle before use.
- Always treat your firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Store firearms and ammunition securely, out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure that your shooting area is clear of people and obstacles.
- Use only the recommended ammunition as specified in this guide.
- Regularly inspect your firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

## Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when shooting.
- Do not use the rifle under the influence of alcohol, drugs, or any substances that may impair your judgment.
- Familiarize yourself with the safety features of the rifle, including the safety selector and magazine release.
- Do not attempt to modify or disassemble the rifle beyond the manufacturer's recommendations.
- If you experience a misfire or hangfire, keep the rifle pointed in a safe direction and wait at least 30 seconds before attempting to clear the malfunction.
- Be cautious when handling the rifle, especially when loading and unloading.
- Ensure that the safety is engaged when the rifle is not in use.

## Instructions for Installation and Usage

### 1. Installation of Accessories:

- Refer to the manufacturer's guidelines for installing any accessories, such as sights or grips.
- Ensure that all accessories are securely fastened before use.

### 2. Loading the Rifle:

- Ensure the rifle is pointed in a safe direction.
- Engage the safety selector to the "safe" position.
- Insert the magazine into the magazine well until it clicks into place.
- Pull the charging handle to the rear and release it to chamber a round.

### 3. Firing the Rifle:

- Ensure that your target is clear and safe.
- Disengage the safety selector to the "fire" position.
- Aim at the target and gently squeeze the trigger to fire.

- Follow through with your aim after firing.

#### **4. Unloading the Rifle:**

- Point the rifle in a safe direction.
- Engage the safety selector to the "safe" position.
- Remove the magazine by pressing the magazine release button.
- Pull the charging handle to the rear to eject any chambered round.
- Visually and physically inspect the chamber to ensure it is empty.

## **Disposal Instructions**

- Dispose of the rifle in accordance with local laws and regulations.
- Ensure that the rifle is rendered inoperable before disposal.
- For ammunition, follow local hazardous waste disposal guidelines.

## **Contact Information for Further Support**

For any inquiries regarding safety or product support, please refer to the manufacturer's contact information provided with your purchase.

## **Conclusion**

By following these safety instructions, you will help ensure a safe and enjoyable experience with your SCHMEISSER AR15 DYNAMIC. Always prioritize safety and responsibility when handling firearms.