

AR-15 - 10.5" - CAL. 223 REM. - Schmeisser AR-15 S4F - 10,5" - Kal. .223 Rem.

The Schmeisser AR15 is a special SL rifle for hunting and safety applications with a free swinging barrel. This firearm with No Flash flash muzzle suppressor, a slim M-Lok handguard and a adjustable gas block made of steel. The Two-Stage trigger guarantees a clearly defined dry trigger. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. Standard delivery with a 10 round magazine and a flip-up sight.

NAME: AR15 S4F

SYSTEM: Semi-automatic rifle

CALIBER: .223 Rem.

WEIGHT: 3.150 kg

LENGTH: 72 cm collapsed, 79 cm extended

BARREL: 26.5 cm

TWIST: 1:9

MAGAZINE: 10 rds

NO IMAGE
AVAILABLE

Attributes

- Name: Schmeisser AR-15 S4F - 10,5" - Kal. .223 Rem.
- Manufacturer: SCHMEISSER
- Product no.: EU2012682
- Mfr. No.: 03-0099M
- Action Type: Semi-Auto
- Barrel Length: 10.5"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Black
- Handguard: Carbine
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-9
- EAN: 0792649432136

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schmeisser AR15 10,5" Kal. .223 Rem.](#)
- [English: Schmeisser AR15 10.5" CAL. 223 REM. Safety Instruction Guide](#)

Sicherheitshinweise für die Schmeisser AR15 10,5" Kal. .223 Rem.

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Schmeisser AR15. Diese Waffe ist für den Einsatz im Jagd und Sportbereich konzipiert. Um sicherzustellen, dass Sie und andere sicher mit diesem Produkt umgehen, sind die folgenden Sicherheitshinweise zu beachten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Waffe nur in dafür vorgesehenen Bereichen verwenden.
- Halten Sie die Waffe immer in einem sicheren Zustand und laden Sie sie nur, wenn Sie bereit sind zu schießen.
- Verwahren Sie die Waffe immer außerhalb der Reichweite von Kindern und unbefugten Personen.
- Tragen Sie beim Schießen stets geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Informieren Sie sich über die Gesetze und Vorschriften bezüglich des Besitzes und Gebrauchs von Feuerwaffen in Ihrem Land oder Ihrer Region.

Besondere Sicherheitsvorkehrungen für die Nutzung

- Überprüfen Sie vor jedem Gebrauch, ob die Waffe sauber und in einwandfreiem Zustand ist.
- Achten Sie beim Laden der Waffe darauf, dass sich keine Personen in der Schusslinie befinden.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen (.223 Remington).
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Seien Sie besonders vorsichtig beim Umgang mit der Waffe, wenn Sie unter Einfluss von Alkohol oder Drogen stehen.

Anweisungen zur Installation und Nutzung

- **Montage des Vorderschafts:** Befolgen Sie die Anweisungen im Handbuch zur Montage des MLok Vorderschafts. Stellen Sie sicher, dass alle Schrauben fest angezogen sind.
- **Anpassung des Gasblocks:** Der verstellbare Stahlgasblock sollte gemäß den Anweisungen im Handbuch eingestellt werden. Überprüfen Sie die Einstellungen regelmäßig.
- **Waffe laden:** Um das Magazin zu laden, drücken Sie den Magazinauslöser und setzen Sie das Magazin ein. Stellen Sie sicher, dass es einrastet.
- **Sicherung aktivieren:** Verwenden Sie die beidseitige Sicherung, um die Waffe in den sicheren Zustand zu versetzen, wenn sie nicht verwendet wird.
- **Schussabgabe:** Zielen Sie immer in eine sichere Richtung. Drücken Sie sanft auf den Abzug, um den Schuss abzugeben.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften.
- Gebrauchte Waffen oder Teile sollten an autorisierte Rücknahmestellen oder Fachhändler abgegeben werden, die die ordnungsgemäße Entsorgung gewährleisten können.

Kontaktinformationen für weitere Unterstützung

Für Fragen zur Sicherheit oder zur Verwendung Ihrer Schmeisser AR15 wenden Sie sich bitte an den Hersteller oder den autorisierten Händler, bei dem Sie das Produkt erworben haben. Es ist wichtig, dass Sie bei Unsicherheiten oder Problemen professionelle Hilfe in Anspruch nehmen.

Schlussfolgerung

Die Einhaltung dieser Sicherheitsrichtlinien hilft Ihnen, sicher und verantwortungsvoll mit Ihrer Schmeisser AR15 umzugehen. Ihre Sicherheit und die Sicherheit anderer hat oberste Priorität. Seien Sie stets aufmerksam und respektieren Sie die Gesetze und Vorschriften in Ihrem Bereich.

Schmeisser AR15 10.5" CAL. 223 REM. Safety Instruction Guide

Introduction

Thank you for choosing the Schmeisser AR15, a semiautomatic rifle designed for hunting and safety applications. This guide provides essential safety instructions and guidelines to ensure the safe use of your firearm. Please read this manual thoroughly before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure that the firearm is not loaded when not in use.
- Store the firearm in a secure location, out of reach of children and unauthorized users.
- Familiarize yourself with the local laws and regulations regarding firearm ownership and use.
- Use only the recommended ammunition for your firearm.
- Regularly inspect your firearm for any signs of damage or wear.
- Always wear appropriate eye and ear protection when shooting.
- Do not consume alcohol or drugs before or during the use of your firearm.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the safety selector is in the "safe" position until you are ready to fire.
- Be aware of your surroundings and ensure that you have a clear and safe shooting area.
- Do not engage in horseplay or distractions while handling your firearm.
- Use the firearm only for its intended purpose.
- Always keep your finger off the trigger until you are ready to shoot.
- Be cautious when loading and unloading the firearm.
- If the firearm fails to fire, keep the muzzle pointed downrange for at least 30 seconds before attempting to clear the malfunction.

Instructions for Installation and Usage

• Installation:

- Ensure that you have a clean and clear workspace.
- Follow the manufacturer's instructions for any accessories or modifications.
- Securely attach the MLoc handguard and ensure it is properly fitted.

• Usage:

- Load the magazine with the appropriate .223 Remington cartridges.
- Insert the magazine into the firearm until it clicks into place.
- Pull the charging handle to chamber a round.
- When ready to fire, ensure the safety selector is in the "fire" position.
- Aim at your target, and gently squeeze the trigger to fire.
- After firing, follow the same steps for unloading the firearm, ensuring the safety selector is in the "safe" position.

Disposal Instructions

- Dispose of unused or expired ammunition in accordance with local regulations.
- For the firearm, contact a licensed firearms dealer or local authority for safe disposal options.
- Do not dispose of the firearm in regular trash or recycling.

Contact Information for Further Support

For any questions or concerns regarding the Schmeisser AR15 or its safe usage, please refer to your local firearms dealer or authority. It is important to have access to professional advice and assistance.

Conclusion

Safety is paramount when handling firearms. By following the guidelines and instructions provided in this manual, you can ensure a safe and responsible experience with your Schmeisser AR15. Always stay informed about safety practices and regulations to protect yourself and others. Thank you for prioritizing safety.